

**Overview of Testing Results for Lead in Drinking Water  
and Corrective Actions for  
Naval Air Station Oceana Child Development Center (Building 450)**

The Navy is committed to maintaining safe drinking water on its installations. City water supplied to the Navy and the Navy's water distribution system is regularly tested and in compliance with the Safe Drinking Water Act. Because lead exposure is a particular concern for children, and lead may be added to drinking water through the pipes, fittings, solder, and fixtures inside a building, the Environmental Protection Agency (EPA) recommends, but does not mandate, that we test the lead content of drinking water in priority areas such as youth centers (YCs), child development group homes (CDGHs), and child development centers (CDCs). The Navy has adopted the recommendation as policy.

Navy environmental personnel conducted lead testing at the Naval Air Station (NAS) Oceana Child Development Center (CDC) Building 450, in accordance with Navy and EPA guidelines. Samples from various locations in the CDC Building 450 were sent to a state-certified laboratory for analysis.

At the CDC Building 450, outlets used for drinking, cooking, and washing were tested. Out of 103 samples collected, zero water outlets tested above the EPA-recommended screening level for lead in drinking water in schools and childcare centers of 15 parts per billion (ppb).

A copy of all test results is enclosed for your information. The test results are presented in two tables:

- Table 1 **Summary of Results** summarizes the data by category of use (e.g., drinking, cooking, washing).
- Table 2 **Summary Statistics** summarizes all the data.

A floor plan of the CDC Building 450 has also been included to show the locations of the fixtures.

**Table 1** provides a description of each sampling location using three columns; *Category*, *Sampling ID*, and *Outlet Description*. The *Category* column gives information about whether the outlet is used for drinking water (water fountain), cooking (food preparation), or washing (primarily hand-washing or brushing teeth). The *Sample ID* column is the identification used to label each sample bottle. The *Outlet Description* column contains additional information to describe the outlet sampled under each category.

The next set of columns in **Table 1** provide *Initial Sampling Results*, and for those locations that exceeded the recommended screening level of 15 ppb the *Re-sampling Results*.

EPA sampling protocol requires water to not be used for between 8 and 18 hours prior to first draw sampling. Therefore, *Initial Sampling Results were from first draw samples collected early in the morning before the YC opened and before any water was used. The Initial Sampling*

*Results* also indicate whether resampling is required and the date that fixtures greater than 15 ppb were secured. None of the sampled outlets exceeded 15 ppb.

If exceedances were detected, the *Re-sampling Results* includes columns for *First Draw* and flushing samples which help determine the source of lead for sampled outlets that exceeded 15 ppb.

To learn more about lead in drinking water in schools and day care centers visit the following EPA website: <https://www.epa.gov/dwreginfo/lead-drinking-water-schools-and-child-care-facilities>.

To learn more about annual water quality at your home, see the annual water quality report at: [https://www.cnic.navy.mil/regions/cnrma/om/environmental\\_support/water\\_quality\\_information.html](https://www.cnic.navy.mil/regions/cnrma/om/environmental_support/water_quality_information.html)

Another resource on drinking water taste, odor, and color can be found at: <https://www.epa.gov/dwstandardsregulations/secondary-drinking-water-standards-guidance-nuisance-chemicals>

To answer general questions you may have on the sampling program contact us at (757) 433-3155 or [jennifer.hayes@navy.mil](mailto:jennifer.hayes@navy.mil).

If you have any health questions or concerns, you are encouraged to contact your health care provider or, if you are a TRICARE beneficiary, use the Region Appointment Center to schedule an appointment with your primary care provider at 1-866-645-4584.

**Enclosures:**

1. Complete Test Results
2. Floor Plan of the SAC/YC

Priority Areas Lead Testing and Corrective Actions (July 2019)  
 NAS Oceana, CDC, Building 450

Table 1. Summary of Results

CATEGORY Water Intended For:	SAMPLE ID	SAMPLE ID NO.	SAMPLING LOCATION DESCRIPTION	INITIAL SAMPLING RESULTS			RE-SAMPLING RESULTS			CORRECTIVE ACTIONS		POST REMEDIATION SAMPLING RESULTS	
				First Draw (ppb)	Reset required?	Date Fixture Sealed? (See Note 1)	Water Fountain 15 min. Follow up Flush Sample - Collected day before First Draw Sampling (ppb)	First Draw (ppb)	Follow up Flush - Collected 30 seconds after First Draw Sampling (ppb)	Description	First Draw (ppb) (See note 2)	Follow up Flush - Collected 30 seconds after First Draw Sampling (ppb)	
DRINKING	OC-450-RM1131-WTCOMB-FD	1	Room 113 water fountain outlet from combination sink	7/19/2019	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM1131-WTCOMB-FD	5	Room 113 water fountain outlet from combination sink	7/23/2019	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM1131-WTCOMB-FD	48	Room 113 water fountain outlet from combination sink	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM1131-WTCOMB-FD	54	Room 113 water fountain outlet from combination sink	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM1131-WTCOMB-FD	60	Room 113 water fountain outlet from combination sink	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM1131-WTCOMB-FD	80	Room 113 water fountain outlet from combination sink	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM1131-WTCOMB-FD	86	Room 113 water fountain outlet from combination sink	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM1131-WTCOMB-FD	92	Room 113 water fountain outlet from combination sink	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM1131-WTCOMB-FD	101	Room 113 water fountain outlet from combination sink	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM1131-WTCOMB-FD	109	Room 113 water fountain outlet from combination sink	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM1131-WTCOMB-FD	111	Room 113 water fountain outlet from combination sink	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
COOKING	OC-450-RM1121-TCOMB-FD	33	Room 112 kitchen sink for dishwashing food prep	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM124-EC-FD	66	Room 124 kitchen sink for dishwashing food prep	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM124-EC-FD	67	Room 124 kitchen sink for dishwashing food prep	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM124-EC-FD	68	Room 124 kitchen sink for dishwashing food prep	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM124-EC-FD	72	Room 124 kitchen sink for dishwashing food prep	12	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM124-EC-FD	73	Room 124 kitchen sink for dishwashing food prep	3	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM124-EC-FD	112	Room 124 kitchen sink for dishwashing food prep	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM124-EC-FD	113	Room 124 kitchen sink for dishwashing food prep	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM124-EC-FD	114	Room 124 kitchen sink for dishwashing food prep	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM124-EC-FD	115	Room 124 kitchen sink for dishwashing food prep	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	BRUSHING/WASHING	OC-450-RM135-TCOMB-FD	4	Room 135 low hand washing and teeth brushing outlet from combination sink	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A
OC-450-RM135-TCOMB-FD		5	Room 135 high hand washing faucet for teeth brushing	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
OC-450-RM135-TCOMB-FD		12	Room 135 high hand washing faucet for teeth brushing	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
OC-450-RM135-TCOMB-FD		15	Room 135 high hand washing faucet for teeth brushing	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
OC-450-RM135-TCOMB-FD		18	Room 135 high hand washing faucet for teeth brushing	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
OC-450-RM135-TCOMB-FD		47	Room 135 high hand washing and teeth brushing outlet from combination sink	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
OC-450-RM135-TCOMB-FD		53	Room 135 low hand washing and teeth brushing outlet from combination sink	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
OC-450-RM135-TCOMB-FD		59	Room 135 low hand washing and teeth brushing outlet from combination sink	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
OC-450-RM135-TCOMB-FD		79	Room 135 low hand washing and teeth brushing outlet from combination sink	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
OC-450-RM135-TCOMB-FD		85	Room 135 low hand washing and teeth brushing outlet from combination sink	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
OC-450-RM135-TCOMB-FD		91	Room 135 low hand washing and teeth brushing outlet from combination sink	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
WASHING	OC-450-RM134-TCOMB-FD	97	Room 134 low hand washing and teeth brushing outlet from combination sink	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM134-TCOMB-FD	103	Room 134 low hand washing and teeth brushing outlet from combination sink	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM134-TCOMB-FD	3	Room 135 high hand washing faucet	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM135-HHW-FD	6	Room 135 high hand washing faucet with motion sensor	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM135-HHW-FD	7	Room 135 low hand washing faucet with motion sensor	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM135-HHW-FD	8	Room 135 low hand washing faucet with motion sensor	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM135-HHW-FD	10	Room 135 high hand washing faucet	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM135-LHW-FD	11	Room 135 low hand washing faucet with motion sensor	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM137-HHW-FD	13	Room 137 high hand washing faucet with motion sensor	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM137-LHW-FD	14	Room 137 low hand washing faucet	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	OC-450-RM138-HHW-FD	16	Room 138 high hand washing faucet with motion sensor	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
OC-450-RM138-LHW-FD	17	Room 138 low hand washing faucet	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
OC-450-RM139-HHW-FD	19	Room 139 high hand washing faucet	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
OC-450-RM139-LHW-FD	20	Room 139 low hand washing faucet	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
OC-450-BATH108-HHW-FD	21	Restroom 108 high hand washing faucet	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
OC-450-BATH109-HHW-FD	22	Restroom 109 high hand washing faucet	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
OC-450-BATH110-HHW-FD	23	Restroom 110 high hand washing faucet	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
OC-450-RM118-HHW-FD	24	Room 118 high hand washing faucet	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
OC-450-RM118-HHW-FD	25	Room 118 high hand washing faucet	non-detect	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		

Priority Areas Lead Testing and Corrective Actions (July 2019)  
 NAS Oceana, CDC, Building 450


CATEGORY		SAMPLING LOCATION DESCRIPTION		INITIAL SAMPLING RESULTS				RE-SAMPLING RESULTS				CORRECTIVE ACTIONS		POST REMEDIATION SAMPLING RESULTS	
Water Intended For:	SAMPLE ID	SAMPLE ID NO.	Outlet Description	First Draw (ppb)	Retest required?	Date Fixture Searched? (See Note 3)	Water Fountain 15 min. Follow up Push Sample - Collected day before First Draw Sampling (ppb)	First Draw (ppb)	Follow up Flush - Collected 30 seconds after First Draw Sampling (ppb)	Description	First Draw (ppb) (See note 3)	Follow up Flush - Collected 30 seconds after First Draw Sampling (ppb)	Recommended Level = 15 ppb	Recommended Level = 15 ppb	
WASHING	DC-450-RM118-LPHW-FD	36	Room 118 low hand washing faucet with motion sensor	7/19/2019	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM117-HHWB-FD	27	Room 117 high hand washing faucet	7/25/2019	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM117-LPHW-FD	28	Room 117 low hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM116-LPHW-FD	29	Room 116 high hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM116-HHWB-FD	30	Room 116 high hand washing faucet	2	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM116-LPHW-FD	31	Room 116 low hand washing faucet	3	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM115-LPHW-FD	32	Room 115 high hand washing faucet	1	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM115-HHWB-FD	34	Room 115 high hand washing faucet	9	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM115-LPHW-FD	35	Room 115 low hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM115-HHWB-FD	36	Room 115 high hand washing faucet	2	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM114-LPHW-FD	37	Room 114 low hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM114-HHWB-FD	38	Room 114 high hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM114-LPHW-FD	39	Room 114 low hand washing faucet with motion sensor	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM120-LPHW-FD	40	Room 120 high hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM120-HHWB-FD	41	Room 120 high hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM120-HHWB-FD	42	Room 120 high hand washing faucet with motion sensor	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM120-HHWB-FD	43	Room 120 high hand washing faucet with motion sensor	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM120-LPHW-FD	44	Room 120 low hand washing faucet	3	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM120-LPHW-FD	45	Room 120 low hand washing faucet	10	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM121-LPHW-FD	46	Room 121 high hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM121-HHWB-FD	49	Room 121 high hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM121-LPHW-FD	50	Room 121 low hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM121-LPHW-FD	51	Room 121 low hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM122-LPHW-FD	52	Room 122 high hand washing faucet	3	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM122-HHWB-FD	55	Room 122 high hand washing faucet with motion sensor	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM122-HHWB-FD	56	Room 122 low hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM123-LPHW-FD	57	Room 123 high hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM123-HHWB-FD	58	Room 123 high hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM123-HHWB-FD	61	Room 123 high hand washing faucet with motion sensor	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM123-LPHW-FD	62	Room 123 low hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM123-LPHW-FD	63	Room 123 low hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-BATH125-HHW-FD	64	Restroom 125 high hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-R124-HHWB-FD	68	Room 124 high hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-R124-HHWB-FD	74	Room 124 high hand washing faucet with eye wash	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM130-HHWB-FD	78	Room 130 high hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM130-HHWB-FD	81	Room 130 high hand washing faucet with motion sensor	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM130-LPHW-FD	82	Room 130 low hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM130-LPHW-FD	83	Room 130 low hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM131-HHWB-FD	84	Room 131 high hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM131-LPHW-FD	87	Room 131 high hand washing faucet with motion sensor	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM131-LPHW-FD	88	Room 131 low hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM133-LPHW-FD	89	Room 133 low hand washing faucet	1	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM133-HHWB-FD	90	Room 133 high hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM133-HHWB-FD	93	Room 133 high hand washing faucet with motion sensor	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM133-LPHW-FD	94	Room 133 low hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM133-LPHW-FD	95	Room 133 low hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM133-HHWB-FD	96	Room 133 high hand washing faucet	1	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM133-HHWB-FD	99	Room 133 high hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM133-LPHW-FD	100	Room 133 low hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM133-LPHW-FD	101	Room 133 low hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM134-HHWB-FD	102	Room 134 high hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM134-HHWB-FD	105	Room 134 high hand washing faucet	2	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		
WASHING	DC-450-RM134-LPHW-FD	106	Room 134 low hand washing faucet	non-detect	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A		

Priority Areas Lead Testing and Corrective Actions (July 2019)  
 NAS Oceana, CDC, Building 450

SAMPLING LOCATION DESCRIPTION		INITIAL SAMPLING RESULTS Recommended Level = 15 ppb			RE-SAMPLING RESULTS Recommended Level = 15 ppb			CORRECTIVE ACTIONS		POST REMEDIATION SAMPLING RESULTS Recommended Level = 15 ppb	
CATEGORY	SAMPLE ID	SAMPLE ID NO.	Outlet Description	First Draw (ppb)	Retest required?	Date Fixture Seized? (See Note 1)	Water Fountain 15 min. Follow up Flush Sample - Collected day before First Draw Sampling (ppb)	First Draw (ppb)	Follow up Flush - Collected 30 seconds after First Draw Sampling (ppb)	First Draw (ppb) (See note 2)	Follow up Flush - Collected 30 seconds after First Draw Sampling (ppb)
Water Intended For:											
SAMPLING DATE				7/19/2019			N/A	N/A	N/A	N/A	N/A
RESULTS DATE				7/23/2019			N/A	N/A	N/A	N/A	N/A
WASHING		107	Room 134 low hand washing faucet	non-detect	No		N/A	N/A	N/A	N/A	N/A

Table 2. Summary Statistics

CATEGORY	INITIAL SAMPLING RESULTS		RE-SAMPLING RESULTS		POST REMEDIATION	
	First Draw	Water Fountain Follow up Flush Sample - Collected day before First Draw Sampling	First Draw (ppb)	Water Fountain Follow up Flush Sample - Collected day before First Draw Sampling	First Draw	Follow up Flush - Collected 30 seconds after First Draw Sampling
Total Drinking	11	0	0	0	0	0
Total Drinking > 15 ppb	6	0	0	0	0	0
Total Cooking	7	0	0	0	0	0
Total Cooking > 15 ppb	0	0	0	0	0	0
Total Washing/Brushing	04	0	0	0	0	0
Total Washing/Brushing > 15 ppb	0	0	0	0	0	0
Total Samples	103	0	0	0	0	0
Total Samples > 15 ppb	0	0	0	0	0	0



**Figure 1.**  
**Building 450 – Floor Plan**  
 NAS Oceana  
 Virginia Beach, Virginia

No.	Type of Fixture	Location Description	Exceeded?
1	Water fountain (cooler)	Hallway	No
2	Utility sink – not for drinking	Janitor Room 104	Not sampled
3	High hand washing faucet	Toddler Room 135	No
4	Low hand washing and teeth brushing outlet from combination sink	Toddler Room 135	No
5	Water fountain outlet from combination sink	Toddler Room 135	No
6	High hand washing faucet with motion sensor	Toddler Room 135	No
7	Low hand washing faucet with motion sensor	Toddler Room 135	No
8	Low hand washing faucet with motion sensor	Toddler Room 135	No
9	High hand washing faucet for teeth brushing	Pretoddler Room 136	No
10	High hand washing faucet	Pretoddler Room 136	No
11	Low hand washing faucet with motion sensor	Pretoddler Room 136	No
12	High hand washing faucet for teeth brushing	Pretoddler Room 137	No
13	High hand washing faucet with motion sensor	Pretoddler Room 137	No
14	Low hand washing faucet	Pretoddler Room 137	No
15	High hand washing faucet for teeth brushing	Pretoddler Room 138	No
16	High hand washing faucet with motion sensor	Pretoddler Room 138	No
17	Low hand washing faucet	Pretoddler Room 138	No
18	High hand washing faucet for teeth brushing	Pretoddler Room 139	No
19	High hand washing faucet	Pretoddler Room 139	No
20	Low hand washing faucet	Pretoddler Room 139	No
21	High hand washing faucet	Restroom 108	No
22	High hand washing faucet	Restroom 109	No
23	High hand washing faucet	Restroom 110	No
24	High hand washing faucet	Infant Room 118	No
25	High hand washing faucet	Infant Room 118	No
26	Low hand washing faucet with motion sensor	Infant Room 118	No
27	High hand washing faucet	Infant Room 117	No
28	High hand washing faucet	Infant Room 117	No
29	Low hand washing faucet with motion sensor	Infant Room 117	No
30	High hand washing faucet	Infant Room 116	No
31	High hand washing faucet	Infant Room 116	No
32	Low hand washing faucet	Infant Room 116	No
33	Kitchen sink for dishwashing, food	Staff Lounge 112	No
34	High hand washing faucet	Infant Room 115	No
35	High hand washing faucet	Infant Room 115	No
36	Low hand washing faucet	Infant Room 115	No
37	High hand washing faucet	Infant Room 114	No
38	High hand washing faucet	Infant Room 114	No
39	Low hand washing faucet with motion sensor	Infant Room 114	No
40	High hand washing faucet	Infant Room 120	No
41	Low hand washing faucet	Infant Room 120	No
42	High hand washing faucet with motion sensor	Infant Room 120	No
43	High hand washing faucet with motion sensor	Infant Room 120	No
44	Low hand washing faucet	Infant Room 120	No
45	Low hand washing faucet	Infant Room 120	No
46	High hand washing faucet	Preschool Room 121	No

No.	Type of Fixture	Location Description	Exceeded?
47	Low hand washing and teeth brushing outlet from combination sink	Preschool Room 121	No
48	Water fountain outlet from combination sink	Preschool Room 121	No
49	High hand washing faucet	Preschool Room 121	No
50	Low hand washing faucet	Preschool Room 121	No
51	Low hand washing faucet	Preschool Room 121	No
52	High hand washing faucet	Preschool Room 122	No
53	Low hand washing and teeth brushing outlet from combination sink	Preschool Room 122	No
54	Water fountain outlet from combination sink	Preschool Room 122	No
55	High hand washing faucet with motion sensor	Preschool Room 122	No
56	Low hand washing faucet	Preschool Room 122	No
57	Low hand washing faucet	Preschool Room 122	No
58	High hand washing faucet	Preschool Room 123	No
59	Low hand washing and teeth brushing outlet from combination sink	Preschool Room 123	No
60	Water fountain outlet from combination sink	Preschool Room 123	No
61	High hand washing faucet with motion sensor	Preschool Room 123	No
62	Low hand washing faucet	Preschool Room 123	No
63	Low hand washing faucet	Preschool Room 123	No
64	High hand washing faucet	Restroom 125	No
65	Dishwasher sprayer – not for drinking	Kitchen 124	Not sampled
66	Kitchen sink for dishwashing, food preparation	Kitchen 124	No
67	Kitchen sink for dishwashing, food preparation	Kitchen 124	No
68	High hand washing faucet	Kitchen 124	No
69	Kitchen sink for dishwashing, food preparation	Kitchen 124	No
70	Dishwasher sprayer – not for drinking	Kitchen 124	Not sampled
71	Utility sink – not for drinking	Kitchen 124	Not sampled
72	Kitchen sink for food preparation	Kitchen 124	No
73	Sprayer for food preparation	Kitchen 124	No
74	High hand washing faucet with eye wash attachment	Kitchen 124	No
75	Ice maker	Kitchen 124	Not sampled
76	Dishwasher sprayer – not for drinking	Kitchen 124	Not sampled
77	Utility sink – not for drinking	Laundry Room 126	Not sampled
78	High hand washing faucet	Preschool/Toddler Room 130	No
79	Low hand washing and teeth brushing outlet from combination sink	Preschool/Toddler Room 130	No
80	Water fountain outlet from combination sink	Preschool/Toddler Room 130	No
81	High hand washing faucet with motion sensor	Preschool/Toddler Room 130	No
82	Low hand washing faucet	Preschool/Toddler Room 130	No
83	Low hand washing faucet	Preschool/Toddler Room 130	No
84	High hand washing faucet	Preschool/Toddler Room 131	No
85	Low hand washing and teeth brushing outlet from combination sink	Preschool/Toddler Room 131	No
86	Water fountain outlet from combination sink	Preschool/Toddler Room 131	No
87	High hand washing faucet with motion sensor	Preschool/Toddler Room 131	No
88	Low hand washing faucet	Preschool/Toddler Room 131	No
89	Low hand washing faucet with motion sensor	Preschool/Toddler Room 131	No
90	High hand washing faucet	Toddler Room 132	No
91	Low hand washing and teeth brushing outlet from combination sink	Toddler Room 132	No

No.	Type of Fixture	Location Description	Exceeded?
92	Water fountain outlet from combination sink	Toddler Room 132	No
93	High hand washing faucet with motion sensor	Toddler Room 132	No
94	Low hand washing faucet	Toddler Room 132	No
95	Low hand washing faucet with motion sensor	Toddler Room 132	No
96	High hand washing faucet	Toddler Room 133	No
97	Low hand washing and teeth brushing outlet from combination sink	Toddler Room 133	No
98	Water fountain outlet from combination sink	Toddler Room 133	No
99	High hand washing faucet	Toddler Room 133	No
100	Low hand washing faucet	Toddler Room 133	No
101	Low hand washing faucet	Toddler Room 133	No
102	High hand washing faucet	Toddler Room 134	No
103	Low hand washing and teeth brushing outlet from combination sink	Toddler Room 134	No
104	Water fountain outlet from combination sink	Toddler Room 134	No
105	High hand washing faucet	Toddler Room 134	No
106	Low hand washing faucet	Toddler Room 134	No
107	Low hand washing faucet	Toddler Room 134	No
108	Hose outlet – not for drinking	Outside	Not sampled
109	Water fountain (bubbler)	Outside	No
110	Hose outlet – not for drinking	Outside	Not sampled
111	Water fountain (bubbler)	Outside	No
112	Kitchen sink for dishwashing, food preparation	Kitchen 124	No
113	Water fountain (bubbler)-offline and not in use	Outside	Not sampled

